
800+

AM/FM Multichannel Receiver



harman/kardon

Instruction Manual

INTRODUCTION

You are now the owner of an instrument unique in concept and design. The Harman/Kardon Model 800+ multichannel receiver encompasses the best of all forms of music reproduction. It may be installed as a stereophonic receiver capable of delivering clean, articulate sound at moderate power levels, or as a quadriphonic receiver that can fill your listening room with spacious, three dimensional sound.

When you listen to your new Harman/Kardon multichannel receiver you will instantly recognize that something truly phenomenal is taking place. The sound, which normally emerges from the speaker boxes, will lose its boundaries and will emanate from all over the room recreating the scope, depth and breadth of the concert hall. The walls of your listening room will seem to disappear and you will find yourself surrounded by a sound field that has the same ambience and spaciousness which marks a live performance. Stereophonic balance and perspective will be retained, but now there will be the addition of depth which will project you into the middle of the hall. Applause, for example, will emerge from the front, sides and rear. And during playback

of a live concert don't be too startled if you hear someone coughing or rustling his program from behind you.

The 4-channel medium is even more dramatic for contemporary music, especially if the music was originally written for four channel reproduction. Sounds bounce back and forth from the corners of the room involving you completely with the performance. It's a new and exhilarating kind of sound that will make listening to music a new experience.

The 800+ bears the heritage of the Harman/Kardon trademark — ultra-wideband frequency response, virtually unmeasurable distortion, and all of the required conveniences so essential for the ultimate enjoyment of high fidelity reproduction.

We urge you to read this manual carefully prior to installing and operating your new receiver. The 800+ is not a complicated instrument. However, there are certain aspects of its operation which should be understood clearly before you install and operate it.

Happy listening!

WARRANTY and SERVICE POLICY

POLICY

We warrant this receiver to be free from defects in material and workmanship under normal use and service, and in accordance with the conditions set forth below. Should a defect occur within the period specified, and provided that the unit is returned to either HARMAN/KARDON or an authorized HARMAN/KARDON warranty station, transportation prepaid, and which our examination shall disclose to our satisfaction to be defective, we will, for a period of two (2) years from date of purchase, either replace or repair and install any defective parts of the receiver free of charge.

EXCEPTIONS

This warranty does not include any obligation as to:

- a) repair or replacement of the wooden enclosure due to damage incurred after initial delivery.
- b) transportation charges to and from the factory or an authorized warranty station.

REGISTRATION

To obtain service under the terms of this policy, it is necessary for you to retain your ORIGINAL BILL of SALE. The enclosed registration card will NOT be considered proof of purchase.

In the event your equipment requires service during the warranty period, only presentation of your original bill of sale to either a factory-authorized repair agency or the factory itself will insure your rights under the policy as outlined in this manual.

This warranty is not applicable to any instrument which shall have been repaired or altered in any way so as, in our judgment, to affect its stability or reliability or has been subject to neglect, misuse, negligence, or accident; or which has had the serial number altered, effaced or removed. Neither shall this warranty apply to any instrument which has been connected other than in accordance with instructions furnished by us.

SERVICE

HARMAN/KARDON has a special customer service division to answer all questions pertinent to the installation and operation of your unit. Please feel free to write to us at any time and we shall endeavor to offer prompt and complete advice.

If your problem cannot be resolved through our combined efforts, we may wish to refer you to a local authorized repair agency, or we may prefer to authorize the return of your unit to the factory. In the event it must be returned, an authorization form and proper packing instructions will be forwarded to you. This authorization form **MUST BE RETURNED** with your unit.

UNDER NO CIRCUMSTANCES SHOULD YOUR UNIT BE SHIPPED TO THE FACTORY WITHOUT PRIOR AUTHORIZATION.

This warranty is in lieu of all other warranties, expressed or implied, and of all other obligations or liabilities on our part, and we neither assume nor authorize any representative or other person to assume for us any other liability in connection with the sale of this instrument.

INSTALLATION

VENTILATION

Heat is a normal operating by-product of your receiver, but the amount developed by your receiver's power amplifier section is rarely high. The cabinet that houses your receiver has been carefully designed to provide the ventilation necessary, under normal operating conditions, when the unit is placed where air can pass freely around it. Placing your receiver in a more closed space will restrict free air flow. The higher temperatures that result within the receiver cabinet can influence performance and adversely affect the life of the unit. If it is inconvenient for you to place your receiver in an open area, be sure you allow at least two (2) inches clearance on each side and the rear panel of the receiver, and four (4) inches clearance above it. If the space in which you place the receiver is completely enclosed (except, of course, for access to operating controls), you must provide several holes or slots below and above its position to allow cool air to flow through the receiver. The bottom clearance of the receiver (provided by its feet) is important too. **NEVER OPERATE YOUR UNIT ON A SOFT SURFACE LIKE A PILLOW OR A RUG-COVERED SHELF, OR COVER IT WITH RECORD JACKETS, WIRES OR CABLES.** Your unit cannot self-ventilate under these conditions.

POWER REQUIREMENTS

Connect the AC line cord to any outlet furnishing 117 volts, 60 Hz AC current. The voltage may vary between 105 and 125 volts. An auxiliary AC power outlet is provided on the rear panel of your receiver. Any accessory equipment (tape recorder, phonograph, etc.) may be connected to this receptacle and will be controlled by the POWER switch on the front panel.

FUSING

A fuse is a safety device used to protect the receiver against possible damage due to overload or short circuits. The 800+ receiver employs five protective fuses. All five are located on the rear panel.

The AC fuse labeled 3AG-3A is used to protect the power supply of the entire system. This fuse is a SLOW BLOW fuse. The other four fuses labeled 3AG-4A LEFT, RIGHT, FRONT and BACK, protect the output stages of the receiver.

The output of your receiver has been designed to operate with a MAXIMUM of 4.0 amperes of current in each channel. Under certain conditions it is possible to draw more than 4.0 amperes through the output stage which would, in turn, blow the speaker fuses. This could be caused by using multiple speaker systems where the total impedance falls below 4 ohms. (See "CONNECTING THE SPEAKERS")

In the event of fuse failure, replace **ONLY** with the same fuse type used. **NEVER** replace with a fuse of a higher rating. To do so will **NOT** protect your receiver and could result in severe damage to it which will not be covered under the warranty policy.

FM ANTENNA

Refer to the special antenna booklet supplied with this set on how to select the FM antenna most suited for your location. In most metropolitan or near-metropolitan areas, the antenna supplied with your receiver will be adequate. However, if you are located a considerable distance from the transmitters, an outdoor antenna may be required. Consult your high fidelity dealer as to the best type to use in your location.

SPEAKER PLACEMENT (See Fig. 1)

The speakers will be referred to as LEFT and RIGHT, FRONT and BACK. Placement of the back speakers will vary with your room size, seating arrangement, and acoustics. At times, it may be advantageous to place the back speakers in line with the listener, either aiming them at the listener, the rear of the room or against the side wall. It has been acknowledged that omnidirectional speakers (i.e. Harman/Kardon HK50) serve well as back speakers in a 4-channel setup because they do not beam the sound at the listener. This gives the illusion of far greater airiness and comes closer to the sound at a live concert. We have illustrated several ways of arranging the back speakers. Some experimentation may be required before you obtain optimum sound dispersion and total surround sound. If you listen predominantly to classical music it is recommended to reflect the back speakers off the walls, or aim them away from the listener. This will tend to soften the sound and create a more natural ambience. If you listen predominantly to contemporary music it may be advantageous to place the back speakers in the corners and beam them into the room.

CONNECTING THE SPEAKERS

Use any type of wire to connect your speakers to your receiver. However, it should be pointed out that the heavier the wire, the lower the loss of power. Ordinary lamp cord, or zip cord as it is sometimes called, is excellent for this application since it can be dressed easily around the molding and it is usually heavy enough to extend great lengths without an appreciable loss in power. Do not drive tacks or staples through the center of the wire since this can result in a short circuit which would either cut the volume level down considerably or short out the sound completely. It is permissible to use approximately 50-60 feet of heavy gauge speaker connecting wire for each speaker without loss of volume.

CONNECT YOUR SPEAKERS WITH CARE. AVOID SHORTS. DO NOT CONNECT THE SPEAKERS WITH THE POWER ON. WORK CAREFULLY TRIMMING ALL LOOSE WIRES ON THE REAR OF THE SPEAKERS AND RECEIVER. THE RECEIVER HAS BEEN DESIGNED TO PREVENT DAMAGE FROM MOMENTARY ACCIDENT SHORTING. HOWEVER, REPETITIVE SHORTING CAN DAMAGE THE OUTPUT DEVICES.




Fig. 1

The 800+ connects two pairs of speaker systems for the front channels, and another two pairs for the back. Any pair may be driven independently or a combination of two pairs may be driven, as selected by the MAIN and REMOTE Speaker Switches. Connect them to the receiver as instructed in the diagrams (Fig. 2 and Fig. 3), taking care not to confuse the FRONT and BACK, LEFT and RIGHT channels, and the plus and minus polarities. Sufficient care should be taken not to short circuit the plus and minus leads.


SPEAKER IMPEDANCE

Each speaker system connected to your 800+ must possess an impedance of from 4 to 16 ohms. Should you wish to drive two pairs of speaker systems simultaneously, they should all have an impedance of 8 ohms or more.

4-CHANNEL OPERATION (See Fig. 2)

Refer to the introductory comments under the heading CONNECTING THE SPEAKERS.

1. Connect one length of lamp cord to the LEFT FRONT speaker.
2. Attach the other end of the lamp cord to the MAIN, FRONT screw terminals marked LEFT + and - on the rear panel of your receiver.
3. Similarly connect another length of lamp cord to your RIGHT FRONT speaker.
4. Attach the other end of the lamp cord to the MAIN, FRONT terminals marked RIGHT + and - on the rear panel of your receiver.
5. Connect a length of lamp cord to your LEFT BACK speaker.
6. Attach the other end of the lamp cord to the MAIN, BACK terminals marked LEFT + and - on the rear panel of your receiver.
7. Connect another length of lamp cord to your RIGHT BACK speaker.
8. Attach the other end of the lamp cord to the MAIN, BACK terminals marked RIGHT + and - on the rear panel of your receiver.
9. Use above steps to connect REMOTE speakers, using REMOTE terminals.




STEREO OPERATION (See Fig. 3)

Refer to the introductory comments under the heading CONNECTING THE SPEAKERS.

1. Connect one length of lamp cord to the LEFT FRONT speaker.
2. Attach the other end of the lamp cord to the MAIN, FRONT terminals marked LEFT + and - on the rear panel of your receiver.
3. Similarly connect another length of lamp cord to your RIGHT FRONT speaker.
4. Attach the other end of the lamp cord to the MAIN, FRONT terminals marked RIGHT + and - on the rear panel of your receiver.
5. Use above steps to connect REMOTE speakers, using REMOTE terminals.

NOTE: BE CERTAIN THAT THE STEREO/4-CH SWITCH LOCATED ON THE REAR PANEL OF THE RECEIVER IS SET IN THE STEREO POSITION FOR DOUBLE POWER STEREO OPERATION.



CAUTION
CONNECT SPEAKERS
WITH CARE. AVOID
SHORTS

STEREO

FIG-3

SPEAKER PHASING

For maximum enjoyment of multichannel sound, it is important to have the four speaker systems in phase. The phase relationship must be correct, not only between the front left and right speaker systems, the back left and right speaker systems, but also between the front and back channels.

When connecting each speaker system to the receiver, be certain to maintain plus and minus polarities.


If your speakers do not have a plus/minus polarity identification, phasing can be accomplished by the following procedure:

1. After connecting your speakers, place the receiver in the MONO mode of operation and the SOUND FIELD BALANCE control to the exact top center position.
2. Play a record, tape or FM broadcast which has a single speaking or singing voice, or a solo instrument.
3. The voice or instrument should appear to be emerging from an area somewhere in the center of the two speakers. If the voice seems to come from both speakers independently, the speakers are out of phase.
4. If you determine that your speakers are out of phase, merely disconnect the leads from only one of the speakers and reverse them. Your stereo system will now be in phase.


This completes the phasing of a pair of speakers for stereo operation. It should be noted that it is not necessary to match the impedance of the speakers to the receiver since the 800+ is a solid state instrument and can accommodate all speakers ranging in impedance from 4 to 16 ohms without special transformers.

Repeat this process for all additional pairs of speakers in your system.

REAR PANEL



FRONT PANEL



OPERATING PROCEDURE

Every control on this receiver serves a specific and useful function and is important for the proper operation of your stereo or 4-Channel system. Read this section carefully so you can take full advantage of all the performance capabilities of this receiver.

REAR PANEL SWITCHES AND CONTROLS

STEREO / 4-CH SWITCH

The 800 + receiver is shipped with the STEREO/4-CH switch in the 4-channel mode. A special safety latch is fitted next to the switch to prevent throwing the switch accidentally while the receiver is turned on.

If you plan to use the 800 + as a DOUBLE-POWER STEREO receiver, first turn off the unit, remove the safety latch and throw the STEREO/4-CH switch to STEREO. NOTE: After changing position of this switch ALWAYS replace the safety latch.

The two front channels now have the capability of delivering double power to your speakers.

NOTE: WHEN THE STEREO/4-CH SWITCH IS IN THE STEREO POSITION THE BACK SPEAKERS ARE INOPERATIVE. IF YOU WISH TO USE THE RECEIVER TO POWER ANY BACK SPEAKERS, FIRST TURN OFF THE RECEIVER. REMOVE THE LATCH AND THROW THE STEREO/4-CH SWITCH TO 4-CH. REPLACE THE PROTECTIVE LATCH.

STEREO THRESHOLD CONTROL

This rear panel control can be adjusted to determine the number of stereo stations the tuner will reproduce in the STEREO FM position of the Function Switch.

In the full counterclockwise position, the automatic switching circuits have maximum sensitivity and all stereo stations within the range of the tuner will be reproduced. However, due to weak signals (or their distance from your antenna) some stations will contain noise levels which degrade performance when reproduced in stereo. In order to reproduce these stations monophonically (when in the STEREO FM position of the Function Switch), rotate the STEREO THRESHOLD control clockwise until only good quality stereo stations are reproduced.

MUTING THRESHOLD CONTROL

This rear panel control adjusts the level at which muting action will take place. Minimum muting action occurs in the full counterclockwise position. Maximum muting is achieved in the full clockwise position.

The full clockwise position will also eliminate stations with poor transmission quality. The control should be adjusted to the point where you receive only those stations which meet your standards of broadcast quality.

CD-4 SEPARATION CONTROLS

The CD-4 circuit in your receiver will give optimum channel separation to the four-channel playback of your CD-4 recordings only when it is adjusted to the characteristics of the specific CD-4 cartridge you will be using. Two controls on the rear panel (one marked LEFT, the other RIGHT) make the adjustment easy.

A CD-4 test record is necessary to set separation. We have provided a record with complete instructions for adjustment on Side 1; band 1. Follow those instructions carefully.

The procedure itself is not complicated, but you may wish to listen to the instructions once or twice before actually making the adjustment. You can use what follows as a guide. It is an exact duplicate of the announcer's script. Before you begin, be certain to set the MODE switch to the CD-4/DISCRETE position, the FUNCTION switch to PHONO, and the SOUND FIELD BALANCE control ("joystick") to its exact center position.

This band of your record will help you adjust the separation of the CD-4 circuitry for optimum performance.

The following tone will be for adjustment of the LEFT channel separation:

- 1. Move your balance control so you hear only the LEFT BACK channel.**
- 2. When the tone begins, adjust the LEFT SEPARATION CONTROL for minimum output from the LEFT BACK speaker system.**

— TONE (15 sec.) —

The next tone will be for adjustment of the RIGHT channel separation:

- 1. Move your balance control so you hear only the RIGHT BACK channel.**
- 2. When the tone begins, adjust the RIGHT SEPARATION CONTROL for minimum output from the RIGHT BACK speaker system.**

— TONE (15 sec.) —

Return your balance control to its neutral position.

Your system is now adjusted for optimum separation. You should now hear my voice on each of the four channels in sequence.

1. Left Front (to appear from LF)
2. Left Back (to appear from LB)
3. Right Front (to appear from RF)
4. Right Back (to appear from RB)

If my voice does not appear through the four channels correctly, check to see that all switches and controls on your equipment are in their correct positions, and go through this adjustment procedure again.

Happy listening.

During adjustment, output in the back channels is actually front channel signal leakage that should be minimized. Complete isolation may not be possible so some leakage may be present. This is a normal condition.

These separation controls may also be used as input level controls when using a conventional stereo phonograph pickup. In this case, set the level of your phonograph signal to be approximately equal to the signal level of your FM tuner.

FRONT PANEL SWITCHES AND CONTROLS

POWER SWITCH

The POWER switch performs the function as its name denotes. It supplies power to the receiver. When the pushbutton is depressed to turn the set ON the power light will illuminate.

HEADPHONE JACKS

The stereo or 4-channel headphone receptacles located on the front panel of your receiver will accept any type of headphone. Stereo phones come with a single plug which should be connected to the FRONT receptacle. 4-channel phones come with two plugs. Connect the front plug to the FRONT receptacle and the back plug to the BACK receptacle. The headphone receptacles are "ON" at all times. To listen only to your phones without having your speakers on, merely set the SPEAKER switches on the front row of pushbuttons to "OFF".

MAIN SPEAKER SWITCH

In order to hear any or all of the speakers connected to your main system, this switch must be depressed.

When in the "ON" position all speakers connected to the main system are "ON". Should you desire to listen to stereo or 4-channel headphones alone, the speakers can be turned off at your discretion.

REMOTE SPEAKER SWITCH

In order to hear any or all of the speakers connected to your remote system, this switch must be depressed.

When in the "ON" position all speakers connected to the remote system are "ON". Should you desire to listen to stereo or 4-channel headphones alone, the speakers can be turned off at your discretion.

EXT DOLBY NR/TAPE MON 2 SWITCH

When an FM station broadcasts a Dolby encoded program, it may be decoded by use of an external Dolby processor. If you use an external processor, the Dolby switch when depressed, will decode an encoded program. If the Dolby button is depressed without an external processor connected, you will get no sound from your speaker system.

Dolby IN receptacles may be used as a 2-channel Tape Monitor provided you are not using the Dolby Function.

TAPE MON 1 SWITCH

If your 4-channel tape recorder has a special monitoring feature, depressing this switch "IN" will permit you to monitor your tapes a split second after they are recorded. When not in use this switch must be in the "OUT" position, otherwise it will defeat the output of the receiver.

This switch and associated rear panel receptacles can also be used as an additional set of stereo or 4-channel high level inputs.

CONTOUR SWITCH

One of the limitations of human hearing is its tendency to lose sensitivity to the very low pitched sounds as the program sound level is reduced. It is this characteristic (known as the Fletcher-Munson effect) which causes one to play music programs at high listening levels in order to experience the full, rich sound available from fine modern recordings.

The Harman/Kardon CONTOUR switch compensates for this effect, thereby eliminating high listening levels as a requisite for full enjoyment of reproduced music. For rich, full-bodied reproduction at low listening levels, throw the CONTOUR switch to the IN position. At high listening levels, the CONTOUR switch has no effect.

FM MUTING SWITCH

The purpose of the muting circuit is to reduce audible noise when tuning from station to station. Since very weak signals may be muted at the same time, the front panel FM MUTING switch may be used to defeat the muting effect on weak signals.

To reduce interstation noise, push the MUTING switch "ON". To defeat the circuit, push the switch "OFF".

HIGH CUT SWITCH

The HIGH CUT filter has been designed to reduce the high frequency response of your receiver. This will reduce annoying record scratch, tape hiss, FM background noise, etc.

LOW CUT SWITCH

At times, record changers, turntables and even some FM stations produce an objectionable low frequency signal that is strong enough to be introduced into the playback system. This is known as rumble and can be cancelled out by the special low frequency cut off filter network included in this receiver. Whenever rumble is present depress the LOW CUT switch.

FUNCTION SWITCH

This switch selects the desired program source to be heard through your music system.

PHONO

This position selects the input receptacles on the rear of your receiver intended for signals from a magnetic phonograph cartridge. Use it for all types of phonograph records playable with this type of cartridge: monophonic, stereophonic, or four-channel (SQ or CD-4).

Any automatic record changer or turntable equipped with a quality stereo magnetic cartridge will play SQ encoded four-channel recordings without special modifications. CD-4 discs, however, require a cartridge specifically designed for CD-4 use. Your dealer will have information on the CD-4 cartridges he handles, or you can write to our Technical Information Department for a list of CD-4 cartridges available on the market.

In order to play SQ records in 4 channel, the MODE switch of your receiver must be in either of the SQ MATRIX positions. To play a CD-4 record, place the MODE switch in the CD-4/DISCRETE position. Your receiver makes use of an exclusive sensing circuit which switches on the CD-4 electronics when the pilot signal impressed in the grooves of all CD-4 discs is present. The switching action is indicated by the steady glow of the CD-4 beacon in the dial glass area. While this sensing circuit can discriminate CD-4 discs from all others, it cannot discriminate SQ four-channel discs from regular stereo ones. You must adjust the mode to SQ MATRIX 1 or 2 to play back SQ discs properly.

The CD-4 Beacon, which is located on the dial glass adjacent to the mode switch indicator lights, will light up in the presence of a CD-4 signal. This visual indication lets you know that you are playing back a discrete four-channel phonograph record.

STEREO FM

This is the normal listening position for all monophonic or stereophonic FM broadcasts. In this position the stereo indicator light and automatic switching circuit built into your receiver are operative. For further details refer to paragraph on "SELECTING A MONOPHONIC OR STEREO FM BROADCAST".

Should you receive a weak stereo signal whose quality has been degraded by noise or poor signal conditions, and you wish to listen to this stereo broadcast monophonically, switch to the FM position.

FM

In this position, you can listen to stereophonic broadcasts, monophonically while monophonic broadcasts will appear unchanged.

DISCRETE FM/AUX 1

In this position, the addition of an accessory 4-channel decoder will permit the reception of discrete FM.

This position, when not being used for discrete FM, may be used as an additional 4-channel auxiliary position. As soon as an FM broadcast system has been selected, Harman/Kardon will be in the position of supplying an appropriate decoder.

AUX 2

This selects the four discrete auxiliary receptacles on the rear panel for playback through your system (tape recorder, cartridge player, etc.).

AM

This selects the AM broadcast section of your receiver.

BASS & TREBLE CONTROLS

These controls are employed to set the tonal balance of your stereo or quad system. The BASS control adjusts the low frequencies, either strengthening or diminishing the intensity of these sounds. The TREBLE control adjusts the higher frequencies in the same manner.

In most instances these controls will be set to the "flat", or center position. If bass or treble adjustment is necessary, do not rotate these controls to their maximum settings. This may introduce distortion especially if your speakers cannot handle the power of the boosted sound. These controls should be used sparingly and with the knowledge that live music is neither excessively sharp nor boomy.

You may adjust both the BASS and TREBLE for front and back pairs of speakers simultaneously or individually. The inner knobs adjust the front speakers and the outer knobs, the back speakers. In order to adjust both pairs, turn either inner or outer knob. In order to adjust front or back only, hold one knob while adjusting the other.

MODE SWITCH

This switch allows you to select the proper mode of operation for the various sources available.

MONO

In this position, all program sources will be reproduced in the monophonic mode.

If an external monophonic source (one channel) is used it may be connected to the appropriate LEFT or RIGHT FRONT input receptacles to reproduce sound in all speakers.

The **1** mode indicator light will be illuminated indicating a monophonic mode of operation.

STEREO

In this position, all stereophonic program sources will be reproduced in the STEREO mode.

All pairs of speakers (one LEFT and one RIGHT) connected to the FRONT terminals will reproduce stereo program material. With the STEREO/4-CH REAR PANEL SWITCH in 4-CH position, speakers connected to the BACK terminals will also reproduce stereo in each pair.

In the STEREO position, the **2** mode indicator light will be illuminated indicating a stereophonic mode of operation.

SQ MATRIX 1/2

These positions may be used to reproduce all SQ program material.


In the SQ MATRIX 1 and SQ MATRIX 2 positions the **4 2 4** mode indicator lights will be illuminated.

These lights denote the channels used from the source material/to recording/to reproduction.

The SQ MATRIX 2 position performs the same function as the SQ MATRIX 1 position except that it changes the relationship of separation between the LEFT and RIGHT and FRONT and BACK speakers.

When in this position the separation between LEFT and RIGHT will be partially reduced from that obtained in the normal SQ MATRIX position and the separation between FRONT and BACK will be increased.


When reproducing full orchestral material, the mode selector should be in the SQ MATRIX 1 position. When reproducing individual instruments or soloists the mode selector switch should be in the SQ MATRIX 2 position.



ENHANCED STEREO

This position should be used to enhance (convert) any stereo source into spatially expanded sound. When playing any stereo source, if your 800+ has been installed utilizing four or eight speakers, the sound will emerge from each speaker filling the room with sound that is almost as exciting as authentic 4-channel. It may also be used to spatially enhance a monophonic source.


In this position the **2 4** mode indicator lights will be illuminated, denoting stereo to 4-channel operation.



CD-4/DISCRETE

This position should be used to play your CD-4 records, or for a discrete 4-channel source (tape) connected to the system.

In this position the **4 4** mode indicator lights will be illuminated, denoting discrete 4-channel operation.



VOLUME CONTROL


The VOLUME control adjusts the signal level of any program material connected to your receiver. It is a four section control which simultaneously adjusts all channels, and its close tracking specifications insure that the relative volume level of each channel will be identical.

SOUND FIELD BALANCE

Your 800+ incorporates a unique four-channel continuously variable balance control.

The nature of stereo or 4-channel reproduction is such that it requires identical channels to attain the highest degree of faithfulness and spatial distribution. Any variation in the efficiency of any channel as compared to the others will disturb this relationship. Since there may be slight differences between program material, room acoustics, etc., your receiver includes a control to balance all channels. Sufficient range is covered by this control to permit rebalancing of the overall system even in cases where major imbalance exists. This control may be set anywhere within its range to attain system balance. It does not necessarily have to be set in the exact center position.

When the BALANCE control is properly set, the apparent sound source will lie in a broad area between all speakers.



TUNING

The tuning knob, located on the right side of the receiver, is used to select the desired station when your FUNCTION switch is in the FM, STEREO FM, or AM position.

SELECTING MONOPHONIC OR STEREO FM BROADCAST

Under normal use for all FM broadcasts the function selector switch should be placed in the STEREO FM position.

Your receiver is equipped with a stereo sensing circuit which will automatically determine whether your unit is receiving a monophonic or stereophonic broadcast, and then automatically adjust the mode of operation.

If the station is transmitting stereo, your receiver will automatically switch on the multiplex section and you will hear the broadcast in full stereo. Should the station conclude broadcasting in stereo, your receiver will automatically switch back to monophonic reception.

Should you receive a weak stereo signal whose quality has been degraded by noise or poor signal conditions, and you wish to listen to this stereo broadcast monophonically, place the function selector switch in the FM position.

STEREO INDICATOR

A stereo indicator is located adjacent to the tuning meter and operates in conjunction with the STEREO FM position of the FUNCTION switch. The indicator visually shows the reproduction of stereo FM through your receiver.

To tune for stereo FM proceed as follows:

1. Place the function selector switch in the STEREO FM position.
2. Tune to the station of your choice using your tuning meter for precise and accurate tuning. Your stereo indicator will now show if you are tuned to a stereo program. If the indicator is off, the program you are listening to is being broadcast monophonically.

TUNING METER

Your receiver incorporates a D'Arsonval movement tuning meter for precise and accurate tuning.

The FM balance meter is designed to operate on a null or "zero" center principle. Therefore, the meter pointer should always be at the dead center position of your meter dial for optimum listening performance. To accomplish this, rotate your tuning knob slowly, in one direction towards the station of your choice. As you tune through the station you will notice the pointer swinging from the left or right past the zero center. THE CORRECT POINT for minimum distortion and optimum FM reception is when the pointer is resting at the "zero" center position.

When used in the AM position, simply tune for maximum indication.

DIAL SCALE

The dial scale on your receiver is marked with three scales: an FM frequency scale (88-108 MHz), a logging scale (0-10), and an AM frequency scale.

Most FM stations operate at frequencies which are not whole numbers (such as 96 Hz as compared to 96.3 Hz). Ideally, each megahertz division on the frequency scale should be divided into 10 parts to enable the user to pinpoint the location of the station. This would require a dial scale which would be longer than the front panel.

The logging scale which is divided in 10 equal parts provides a means of finding your favorite station, once you have noted its position on the logging scale. For example, in New York City, WQXR operates at 96.3 MHz. After locating this station through the use of the frequency scale (between 96 and 98 MHz), you find that the pointer may fall on 4.2 on the logging scale. Make a note of this setting. For future tuning to WQXR simply set the pointer to 4.2 on the logging scale.

EQUALIZATION

In order to achieve good reproduction of the wide range of frequencies in music and to make necessary adjustment for the limitations of the recording technique, record manufacturers have found it necessary to modify the actual frequency response of the music while it is being recorded. Thus, to avoid overcutting and consequent distortion, a measured and deliberate reduction is effected in low frequency response by selecting a "turnover frequency" and recording attenuated response below that point. To assure optimum signal to noise at the high frequency end when the record is played at home, the highs are deliberately exaggerated during the recording process. A measured and deliberate boost is effected above a certain frequency. This combination of deliberate exaggeration at the low and high ends of the frequency spectrum can be expressed in a recording curve. When the record is played, a mirror image of that curve should be available so that the ideal "flat" response may be achieved.

The PHONO position of the function switch automatically introduces the proper equalization.

HUM AND NOISE

In any high fidelity installation, hum may be caused by the interconnection of a record player, tuner and amplifier, as a result of the cables and different grounds. If hum is experienced with your receiver, disconnect everything but the speakers from the receiver. If hum persists, reverse the AC line cord. Plug in the record player and if hum appears, reverse the record player power plug and connect a single lead from the record player chassis to the ground post on the rear of the receiver chassis. Connect your other devices in this manner. CAUTION: Hum may also be induced by defective connecting cables or by running these cables too close to a strong AC line cord.

CONNECTING RECORD PLAYERS


The following drawings show connections of various types of accessory equipment. With each drawing a "typical" application is described.

Refer to paragraph "MODE SWITCH" for information and explanation.

CONNECTING A MONO RECORD PLAYER

Typical Operating Conditions

Function Switch: Set to PHONO position
 Mode Switch: Set to MONO position



CONNECTING A STEREO RECORD PLAYER

Typical Operating Conditions (Stereo Record)


Function Switch: Set to PHONO position
 Mode Switch: Set to STEREO position

Typical Operating Conditions (SQ Record)

Function Switch: Set to PHONO position
 Mode Switch: Set to SQ MATRIX 1 or
 SQ MATRIX 2 position

Typical Operating Conditions (CD-4 Record)

Function Switch: Set to PHONO position
 Mode Switch: Set to CD-4/DISCRETE position



CONNECTING A TAPE RECORDER

CONNECTING A STEREO TAPE RECORDER


Typical Operating Conditions

To Record

Function Switch: Set to source desired

To Playback/Monitor

Tape Mon 1 Switch: Set to "IN" position
 Mode Switch: Set to STEREO position



CONNECTING A 4-CHANNEL TAPE RECORDER

Typical Operating Conditions


To Record

Function Switch: Set to source desired

To Playback/Monitor

Tape Mon 1 Switch: Set to "IN" position
 Mode Switch: Set to CD-4/DISCRETE position

NOTE: In order to make a 4-CH recording, it is necessary to have a 4 channel source connected to the recorder.



CONNECTING TWO STEREO TAPE RECORDERS

Typical Operating Conditions

To Record on Tape Recorder #1

Function Switch: Set to source desired

To Playback/Monitor from Tape Recorder #1

Tape Mon 1 Switch: Set to "IN" position
Mode Switch: Set to STEREO position

To Record on Tape Recorder #2

Function Switch: Set to source desired


To Playback/Monitor from Tape Recorder #2

Tape Mon 2 Switch: Set to "IN" position
Mode Switch: Set to STEREO position

To Record from Tape Recorder #1 to Tape Recorder #2

Tape Mon 1 Switch: Set to "IN" position

NOTE: When using two tape recorders, attached as shown, TAPE MON 2 will take precedence over TAPE MON 1



CONNECTING TWO 4-CHANNEL TAPE RECORDERS

Typical Operating Conditions

To Record on Tape Recorder #1

Function Switch: Set to source desired

To Playback/Monitor from Tape Recorder #1


Tape Mon 1 Switch: Set to "IN" position
Mode Switch: Set to CD-4/DISCRETE position

To Record on Tape Recorder #2

Function Switch: Set to source desired

To Playback from Tape Recorder #2

Function Switch: Set to AUX 2 position
Mode Switch: Set to CD-4/DISCRETE




CONNECTING ACCESSORIES

TO CONNECT EXTERNAL DOLBY NR

To Operate


- Function Switch: Set to source desired
- Ext Dolby NR Switch: Set to "IN" position
- Mode Switch: Set to STEREO position



TO CONNECT FOR DISCRETE FM

To Operate

- Function Switch: Set to DISCRETE FM/AUX position
- Mode Switch: Set to CD-4/DISCRETE position



SPECIAL APPLICATION

The versatility of the 800+ receiver permits the utilization of 2 completely separate stereo systems reproducing different program material.

Typical Example

System #1 — Connect left and right speakers to the front left and right speaker terminals.

System #2 — Connect left and right speakers to the back left and right speaker terminals.

Connect a pair of patch cords from the front tape out receptacles to the front tape monitor receptacles.

Connect a stereo tape recorder output to the back tape monitor receptacles.

Mode switch to CD-4/DISCRETE position.

With the TAPE MONITOR 1 switch depressed, System #1 will reproduce any source selected by the function switch. System #2 will reproduce the output of the tape recorder.

The VOLUME CONTROL should be used to set the overall level.


The SOUND FIELD BALANCE control should be used to alter the levels of the separate systems.

The front and back TONE controls will function separately for each system.

The STEREO/4-CH rear panel switch must be in the 4-CH position.

SERVICE

If this instrument should not perform properly during the first two (2) years after date of purchase, contact the factory for instructions. The factory has many authorized warranty service stations in the United States. To aid us in selecting a service station convenient to you, it would be helpful if you would indicate which major city is closest to your home. Please write our Customer Service Department, Harman/Kardon, Incorporated, 55 Ames Court, Plainview, New York 11803. Be sure to include the model and serial numbers of the unit. A brief description of your other components is often of help in answering your questions. DO NOT return this instrument to Harman/Kardon without first receiving authorization.



TROUBLESHOOTING HINTS

SYMPTOM

POSSIBLE CAUSES AND SOLUTIONS

No sound, on/off switch and dial are not lighted.

Check A.C. plug in wall outlet. Check on/off switch — sticking. Check main fuse. Replace with exactly same type and rating.

No sound, on/off switch and dial are lighted.

Check speaker switches. Must be depressed. Check tape monitor switch (should not be depressed). Check all protective speaker fuses. Replace fuse with exactly same type and rating. Check connections at receiver and speakers for shorted or loose connection.

**Phono operative. AM operative.
FM noisy or inoperative.**

Check FM antenna orientation and connection.

**AM and FM operative.
Phono inoperative.**

Check phono cartridge connections at phonograph and at receiver. Check phono stylus. Inserted into pickup and secure?

Distorted AM and FM sound.

Check antenna orientation. Does sound clear up when you touch antenna post, or change its direction? You may require a better antenna.

Hum or Buzz on phono.

Check shielded cables for loose or broken ground connection. Phonograph chassis should be grounded to receiver. Check location of record player and its relationship to the receiver. Your changer may be picking up a hum field from the power transformers. Move changer further away from receiver.

Speaker fuses blow out.

Check wiring to speakers. Be sure there are no shorts (nail through center of wire, loose ends touching).

Speaker fuses blow out occasionally.

This can occur if you play your music at excessively loud levels, especially if your speakers have an impedance of 4 ohms, or lower. Also with bass control at maximum.

