


# CDR 26 FRONT-PANEL INFORMATION DISPLAY



- A** Coaxial Digital Indicator
- B** Optical Digital Indicator
- C** Analog Indicator
- D** Front-Panel Input Indicator
- E** Sync Indicator
- F** Repeat Indicators
- G** Random Indicators
- H** Repeat Status Indicators
- I** Program Indicators

- J** Level Indicators
- K** Speed Indicators
- L** 1-Track Dubbing Indicator
- M** Dubbing Indicator
- N** Sample-Rate Conversion Indicator
- O** Play/Pause Indicators
- P** Record Indicator
- Q** R/RW Indicator
- R** CD Indicators

- S** Time Indicators
- T** Remaining Time Indicators
- U** Recorded Time Indicator
- V** Total Time Indicators
- W** Track Time Indicators
- X** Manual Indicator
- Y** Information Displays