





1. Instruction manual ass'y - Accessories



NO	DESCRIPTION	PARTS NO.	Q.ty
1	POLY BAG		1
2	CARD WARRANTY	CQE1A172X	1
3	AM LOOP ANTENNA ASS'Y	CSA1A027Z	1
4	BATTERY		2
5	INSTRUCTION MANUAL		1
6	FM 1 POL ANT(UL)	CSA1A019Z	1
7	REMOCON ASS'Y(ZONE2)	CARTZONE24	1
8	CORD,POWER(UL)	CJA2A070Z	1
9	SHEET GUIDE	CQE1A381Z	1
10	STAPLE		3
11	COVER ASS'Y		1
	1 COVER A	CGR1A331H63	1
	2 COVER B	CBT1A332H63	1
	3 SHEET , FRONT COVER	CQE1A219Z	1
	4 PAD, COVER	CPS1A676	1
	5 BAG, POLY		1
12	IMAGE BROCHURES		11
A	REMOCON ASS'Y	RB46G00	1
B	MICROPHONE ASS'Y	CJXAVR340MICRO	1

2. Package Drawing



NO	DESCRIPTION	PARTS NO.	Q.ty
1	ACCESSORY		1
2	REMOCON ASS'Y	RB46G00	1
3	SNOW,PAD(L)	CP55A564Z	1
4	SNOW,PAD(R)	CP55A565Z	1
5	AVR354	AVR 354	1
6	BOX,OUT CARTON	CPG1A854W	1
7	MICROPHONE ASS'Y	CJXAVR340MICRO	1
8	BRIDGE 2 ASS'Y	THE BRIDGE II AVR	1