





1. Instruction manual ass'y - Accessories



NO	DESCRIPTION	PARTS NO.	Q,ty
1	POLY BAG		1
2	CARD WARRANTY	CQE1A172X	1
3	AM LOOP ANTENNA ASS'Y	CSA1A027Z	1
4	BATTERY		3
5	BATTERY		2
6	INSTRUCTION MANUAL	COX1A1185Z	1
7	FM 1 POL ANT(UL)	CSA1A019Z	1
8	REMOCON ASS'Y(ZONE2)	HARTZONE23	1
9	CORD,POWER(UL)	CJA2A070Z	1
10	SHEET GUIDE		1
11	STAPLE		3
12	COVER ASS'Y	CGRAVR130ZA	1
	1 COVER A	CGR1A331M7H43	1
	2 COVER B	CGR1A332M7H43	1
	3 SHEET,FRONT COVER	CQE1A219Z	1
	4 PAD, COVER	CPS1A676	1
	5 BAG ,POLY		1
13	IMAGE BROCHURES		1
A	REMOCON ASS'Y	CARTAVR347	1
B	MICROPHONE ASS'Y	CJXAVR340MICRO	1

2. Package Drawing

AVR347



NO	DESCRIPTION	PARTS NO.	Q,ty
1	MANUAL ASS'Y		1
2	REMOCON ASS'Y	CARTAVR347	1
3	FOAM PAD (L)	CPS6A564	1
4	FOAM PAD (R)	CPS6A565	1
5	AVR347	AVR347	1
6	BOX,OUT CARTON	CPG1A822W	1
7	MICROPHONE ASS'Y	CJXAVR340MICRO	1