


Packaging/accessories



Item	Description	Part Number	Qty
1	Outer Carton BDP1	76-982790-0ATB2	1
	Outer Carton BDP10	76-982790-0ATB1	1
2	Front Protector		1
3	Plastic Bag		1
4	BDP1	BDP 1	1
	BDP10	BDP 10	1
5	Foam End, Right		1
6	Corner Protectors		4
7	Corner Protectors		4
8	HDMI cable	46-HDI015-19G	1
	3-conductor analog audio/video cable	41-UH1500-0KKCD	1
	AC power cord BDP1	51-BC0150-0LSA9-M	1
	AC power cord BDP10	51-DC0150-0CRA4	1
9	Owner's Manual BDP1 or BDP10	Visit www.harmankardon.com	1
10	Plastic Bag		1
11	Remote control BDP1 or BDP10	RB17H00 or 06-RB17H0-00X	1
	AA Batteries		2
12	Foam End, Left		1