



1. Instruction manual ass'y - Accessories



2. Package Drawing



ACCESSORY-1			
NO	DESCRIPTION	PARTS NO.	Q, ty
1	POLY BAG		1
2	AM LOOP ANTENNA ASS' Y	CSA1A027Z	1
3	BATTERY		2
4	FM 1 POL ANT	CSA1A019Z	1
5	COVER ASS' Y	CGRHK3390ZA	1
	1 COVER A	CGR1A445	1
	2 COVER B	CGR1A446	1
	3 ORNAMENT , AL A	CGX1A391C66	1
	4 ORNAMENT , AL B	CGX1A392C66	1
	5 SHEET, FRONT COVER	CQE1A392Z	1
	6 PAD , COVER	CPS1A676	1
	7 BAG , POLY		1
6	IMAGE BROCHURES		1
7	REMOCON ASS' Y	CARTHK3490	1
8	STAPLE		3
9	WARRANTY CARD	CQE1A172X	1
10	MANUAL, INSTRUCTION	visit www.harmanardon.com	1

NO	DESCRIPTION	PARTS NO.	Q, ty
1	ACCESSORY-1		1
2	SNOW, PAD(L)	CPS5A564	1
3	SNOW, PAD(R)	CPS5A565	1
4	HK3490	HK 3490	1
5	BOX, OUT CARTON	CPG1A743Q	1