




1. Instruction manual ass'y - Accessories




POLY BAG




CARD WARRANTY




AM LOOP ANTENNA ASS'Y




BATTERY ASS'Y




MANUAL INSTRUCTION




FM 1 POLE ANT(UL)




REMOCON TRANSMITTER ASS'Y




SHEET GUIDE



SHEET



STAPLE



COVER ASS'Y





IMAGE BROCHURES

NO	DESCRIPTION	PARTS NO.	Q.ty
1	POLY BAG		1
2	CARD WARRANTY	CQE1A172X	1
3	AM LOOP ANTENNA	CSA1A027Z	1
4	BATTERY		3
5	INSTRUCTION MANUAL	CQX1A1132Y	1
6	FM 1 POL ANT(UL)	CSA1A019Z	1
7	REMOCON TRANSMITTER ASS'Y	CARTAVR145	1
8	SHEET GUIDE(QUICK START GUIDE)	CQE1A297Z	1
9	SHEET INPORTANT		1
10	STAPLE		3
11	DOOR KIT	CGRAVR130ZA	1
1	FRONT COVER "A", SILVER	CGR1A331M7H43	1
2	FRONT COVER "B", SILVER	CGR1A332M7H43	1
3	SHEET,FRONT COVER	CQE1A219Z	1
4	PAD, COVER	CPS1A676	1
5	BAG,POLY		1
12	IMAGE BROCHURES		1

2. Package Drawing



NO	DESCRIPTION	PARTS NO.	Q.ty
1	MANUAL ASS'Y		1
2	SNOW,PAD(L)	CPS6A564	1
3	SNOW,PAD(R)	CPS6A565	1
4	SET	AVR145	1
5	BOX,OUT CARTON	CPG1A820Z	1