


# AVR 7200 FRONT PANEL INFORMATION DISPLAY



- A** Upper Display Line
- B** Lower Display Line
- C** OSD Indicator
- D** Multiroom Indicator

- E** Speaker/Channel Input Indicators
- F** PRESET Indicator
- G** MEMORY Indicator
- H** STEREO Indicator

- I** TUNED Indicator
- J** AUTO Indicator
- K** 192kHz Indicator
- L** 96kHz Indicator