












1. Instruction manual ass'y - Accessories



NO	DESCRIPTION	PARTS NO.	Q,ty
1	POLY BAG		1
2	CARD WARRANTY	CQE1A172X	1
3	AM LOOP ANTENNA	CSA1A020Z	1
4	INSTRUCTION MANUAL		1
5	FM 1 POL ANT(UL)	CSA1A019Z	1
6	REMOCON TRANSMITTER ASS'Y	CARTAVR254	1
7	SHEET GUIDE(QUICK START GUIDE)	CQE1A380Z	1
8	STAPLE		3
9	COVER ASS'Y	CGRAVR154ZA	1
	1 COVER A	CGR1A331H63	1
	2 COVER B	CGR1A332H63	1
	3 SHEET,FRONT COVER	CQE1A219Z	1
	4 PAD,COVER	CPS1A676	1
	5 BAG,POLY		1
10	IMAGE BROCHURES		1



Item	Description	Part Number	Qty
1	Manual, remote, antenna ass'y		1
2	Foam End Pad, Left	CPS5A564Z	1
3	Foam End Pad, Right	CPS5A565Z	1
4	AVR254 Receiver	AVR 254	1
5	AVR254 Outer Carton	CPG1A854Y	1
6	Microphone Assembly	CJXAVR340MICRO	1