




1. Instruction manual ass'y - Accessories




POLY BAG




CARD WARRANTY




AM LOOP ANTENNA ASS'Y




BATTERY ASS'Y




MANUAL INSTRUCTION




FM 1 POLE ANT(UL)




REMOCON TRANSMITTER ASS'Y



SHEET GUIDE



STAPLE



COVER ASS'Y






IMAGE BROCHURES

| NO | DESCRIPTION | PARTS NO. | Q.ty |
|----|---------------------------|---------------|------|
| 1 | POLY BAG | | 1 |
| 2 | CARD WARRANTY | CQE1A172X | 1 |
| 3 | AM LOOP ANTENNA ASS'Y | CSA1A027Z | 1 |
| 4 | BATTERY | | 3 |
| 5 | INSTRUCTION MANUAL | CQX1A1184Z | 1 |
| 6 | FM 1 POL ANT(UL) | CSA1A019Z | 1 |
| 7 | REMOCON TRANSMITTER ASS'Y | CARTAVR247 | 1 |
| 8 | SHEET GUIDE | CQE1A330Z | 1 |
| 9 | STAPLE | | 3 |
| 10 | COVER ASS'Y | CGRAVR130ZA | 1 |
| 1 | COVER A | CGR1A331M7H43 | 1 |
| 2 | COVER B | CGR1A332M7H43 | 1 |
| 3 | SHEET, FRONT COVER | CQE1A219Z | 1 |
| 4 | PAD, COVER | CP51A676 | 1 |
| 5 | BAG, POLY | | 1 |
| 11 | IMAGE BROCHURES | | 1 |

2. Package Drawing

AVR247



| NO | DESCRIPTION | PARTS NO. | Q.ty |
|----|------------------|----------------|------|
| 1 | MANUAL ASS'Y | | 1 |
| 2 | SNOW, PAD(L) | CP56A564 | 1 |
| 3 | SNOW, PAD(R) | CP56A565 | 1 |
| 4 | AVR247 | AVR247SET | 1 |
| 5 | BOX, OUT CARTON | CPG1A822X | 1 |
| 6 | MICROPHONE ASS'Y | CJXAVR340MICRO | 1 |