





1. Instruction manual ass'y - Accessories



NO	DESCRIPTION	PARTS NO.	Q, ty
1	POLY BAG		1
2	CARD WARRANTY	CQE1A172X	1
3	ANT, AM LOOP	CSA1A032Z	1
4	INSTRUCTION MANUAL	visit www.harmankardon.com	1
5	FM 1 POL ANT(UL)	CSA1A019Z	1
6	SHEET, QUICK SETUP GUIDE		1
7	STAPLE		3

A	REMOCON ASS'Y	CARTAVR2600/120	1
B	MICROPHONE ASS'Y	CJXAVR340MICRO	1

2. Package Drawing



NO	DESCRIPTION	PARTS NO.	Q, ty
1	ACCESSORYS		1
2	REMOCON ASS'Y	CARTAVR2600/120	1
3	SNOW, PAD(L)	CPS5A564Z	1
4	SNOW, PAD(R)	CPS5A565Z	1
5	AVR 2600	AVR 2600	1
6	BOX, OUT CARTON	CPG1A891Y	1
7	MICROPHONE ASS'Y	CJXAVR340MICRO	1