

AVR 445 SETTINGS WORKSHEETS

SYSTEM DEFAULTS

The table in this section shows the factory default settings for all inputs to give you a picture of the AVR 445's initial settings. You may then decide whether any item needs to be changed so that it is more appropriate for your specific installation. Any of the settings shown may be changed as shown in the System Configuration section of the owner's manual.

TABLE 1: INPUT DEFAULTS

INPUT	AUDIO INPUT	VIDEO INPUT	COMPONENT VIDEO INPUT	RECORD OUTPUT
Video 1	ANALOG	AUTO	OFF	ANALOG
Video 2	ANALOG	AUTO	OFF	ANALOG
Video 3	OPTICAL 1	AUTO	COMPONENT 1	ANALOG
Video 4	ANALOG	AUTO	COMPONENT 2	ANALOG
DVD	COAX 1	AUTO	COMPONENT 3	ANALOG
HDMI 1	OPTICAL 3	HDMI 1	---	DSP DOWNMIX
HDMI 2	COAX 3	HDMI 2	---	DSP DOWNMIX
Tuner	ANALOG	AUTO	OFF	ANALOG
XM	---	AUTO	OFF	ANALOG
CD	ANALOG	AUTO	OFF	ANALOG
Tape	ANALOG	AUTO	OFF	ANALOG
DMP/The Bridge	ANALOG	AUTO	OFF	ANALOG
6/8 CH Direct	ANALOG	AUTO	OFF	ANALOG
USB	---	AUTO	OFF	DSP DOWNMIX

System Default and Personal Settings Worksheets

The worksheets in this section show the system defaults for the global settings on your AVR 445. Once your system is configured manually, or through the use of EzSet/EQ II, where applicable, we recommend that you use the "Your System Settings" column to record your personal preferences so that they may be restored in the event the AVR's memory is lost due to an extended power outage, system upgrade, processor reset, or other major service to your unit.

Worksheet A: Surround Configuration Defaults and Settings

Feature	System Default	Your System Settings
Logic 7 Global	Off	
Default Surround	Original	
Dolby Pro Logic II Music Center Width	3	
Dolby Pro Logic II Music Dimension	0	
Dolby Pro Logic II Music Panorama	Off	
Dolby Pro Logic IIx Music Center Width	3	
Dolby Pro Logic IIx Music Dimension	0	
Dolby Pro Logic IIx Music Panorama	Off	
Night Mode	Off	

AVR 445 SETTINGS WORKSHEETS

Worksheet B: Delay Defaults and Setting

Feature	System Default	Your System Settings
Front Left	12.0 Feet	
Center	12.0 Feet	
Front Right	12.0 Feet	
Surround Right	10.0 Feet	
Surround Back Right	10.0 Feet	
Surround Back Left	10.0 Feet	
Surround Left	10.0 Feet	
Subwoofer	12.0 Feet	

Worksheet C: System Defaults and Settings

Feature	System Default	Your System Settings
Front L/R Speaker Size & X-Over	Small – 100Hz	
Center Speaker Size & X-Over	Small – 100Hz	
Surround L/R Speaker Size & X-Over	Small – 100Hz	
Surround Back Speaker Size & X-Over	None	
LFE LP Filter	100Hz	
Sub Mode	Sub	
Channel Adjust	Global	
Sub Size	10 in/250mm	
VFD Fade Time-Out	Off	
VFD Brightness	Full	
Volume Default	Off	
Volume Default Set	-25dB	
Semi-OSD Time-Out	5 Sec	
Full-OSD Time-Out	20 Sec	
DMP Auto Power	Off	
Surround Back Amps	Main	
Carrier Out	Zone II	

