

# AVR 347 WORKSHEETS

## Default settings and worksheets

**Table A1 – Source Input Setting Defaults**

Source	DVD	HDMI 1	HDMI 2	Video 1	Video 2	Video 3	Video 4	The Bridge/ DMP	CD	Tape	Tuner	6-/8- Channel	XM
Title											TUNER		XM
Video Input	Comp V 1	HDMI 1	HDMI 2	Comp V 2	Comp V 3	Composite	Composite	The Bridge/ DMP	Comp V1	Comp V1	Comp V1	Comp V1	Comp V1
Audio Input	Coax 1	HDMI 1	HDMI 2	Analog	Optical 1	Analog	Analog	Analog (The Bridge/ DMP)	Analog	Analog	Analog (Tuner)	Analog (6-/8- Channel)	Analog (Tuner)
Auto Poll	On	Off	Off	On	On	On	On	Off	On	On	Off	Off	Off
Surround Mode†	Logic 7 7CH Music	Logic 7 7CH Music	Logic 7 7CH Music	Logic 7 7CH Music	Logic 7 7CH Music	Logic 7 7CH Music	Logic 7 7CH Music	Logic 7 7CH Music	Logic 7 7CH Music	Logic 7 7CH Music	Logic 7 7CH Music	Logic 7 7CH Music	Logic 7 7CH Music

† The default shown is the preferred surround mode for PCM and Analog audio sources.

**Table A2 – Speaker/Channel Setting Defaults**

Source	DVD	HDMI 1	HDMI 2	Video 1	Video 2	Video 3	Video 4	The Bridge/ DMP	CD	Tape	Tuner	6-/8- Channel	XM
Left/Right Speaker Size	Small	Small	Small	Small	Small	Small	Small	Small	Small	Small	Small	Large	Small
Center Speaker Size	Small	Small	Small	Small	Small	Small	Small	Small	Small	Small	Small	Large	Small
Surround Speaker Size	Small	Small	Small	Small	Small	Small	Small	Small	Small	Small	Small	Large	Small
Surround Back Speaker Size	Small	Small	Small	Small	Small	Small	Small	Small	Small	Small	Small	Large	Small
Subwoofer	Sub	Sub	Sub	Sub	Sub	Sub	Sub	Sub	Sub	Sub	Sub	Sub	Sub
Left/Right Speaker Crossover	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	N/A	100Hz
Center Speaker Crossover	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	N/A	100Hz
Surround Speaker Crossover	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	100Hz	N/A	100Hz
Subwoofer Crossover	Left/Right	Left/Right	Left/Right	Left/Right	Left/Right	Left/Right	Left/Right	Left/Right	Left/Right	Left/Right	Left/Right	N/A	Left/Right

**Table A3 – Delay Setting Defaults**

Speaker Position	Distance From Speaker to Listening Position	Your Delay Settings
Front Left	10 feet	
Center	10 feet	
Front Right	10 feet	
Surround Right	10 feet	
Surround Left	10 feet	
Subwoofer	10 feet	
A/V Sync Delay	0mS	

# AVR 347 WORKSHEETS

**Table A4 – Source Input Settings**

Source	DVD	HDMI 1	HDMI 2	Video 1	Video 2	Video 3	Video 4	The Bridge/DMP	CD	Tape	Tuner	6-/8-Channel	XM
Title													
Video Input													
Audio Input								The Bridge/DMP			Tuner	6-/8-Channel	Tuner
Auto Poll								---			---	---	
Surround Mode													
Tone Mode													
Bass													
Treble													
Video Mode													

**Table A5 – Speaker/Channel Settings**

Source	DVD	HDMI 1	HDMI 2	Video 1	Video 2	Video 3	Video 4	The Bridge/DMP	CD	Tape	Tuner	6-/8-Channel <sup>††</sup>	XM
Left/Right Speaker Size												N/A	
Center Speaker Size												N/A	
Surround Speaker Size												N/A	
Subwoofer												N/A	
Left/Right Speaker Crossover												N/A	
Center Speaker Crossover												N/A	
Surround Speaker Crossover												N/A	
Subwoofer Crossover												N/A	
Left Channel Level <sup>†††</sup>													
Right Channel Level <sup>†††</sup>													
Center Channel Level <sup>†††</sup>													
Surround Left Channel Level <sup>†††</sup>													
Surround Right Channel Level <sup>†††</sup>													
Surround Back Left Channel Level <sup>†††</sup>													
Surround Back Right Channel Level <sup>†††</sup>													
Subwoofer Channel Level <sup>†††</sup>													

<sup>††</sup> The 6-/8-Channel Inputs are "direct" inputs, meaning their signals are passed directly to the volume control without any bass management processing. Thus, the speaker sizes are always full range, and it isn't possible to adjust speaker size or crossover.

<sup>†††</sup> Channel levels vary by surround mode rather than source input.

# AVR 347 WORKSHEETS

**Table A6 – Remote Control Codes**

Source Input	Product Type (circle one)	Remote Control Code
Video 1	VCR, PVR	
Video 2	Cable, Satellite	
Video 3	TV	
Video 4	TV	
DVD	DVD	
CD	CD, CDR	
Tape	Cassette	
HDMI 1	DVD, VCR, PVR, Cable Satellite	
HDMI 2	DVD, VCR, PVR, Cable Satellite	

**Table A7 – System Settings**

Feature	Default Setting	Your Setting
VFD Fade Timeout	Off	
Volume Default	Off	
Default Volume Set	-25dB	
Semi-OSD Timeout	5 seconds	
Full-OSD Timeout	20 seconds	
Default Surround Mode	On	